



WDC10HC
InstaShow™
Quick Start Guide




1




2


A




B




C




D




2-A




2-B




2-C




2-D






3


A




B




3-A




3-B






4



5



6



Support.BenQ.com



Online Manual



Product Support