

V1

PICZO



USER MANUAL

Model: NOVA Pro

PICZO

1	FCC Compliance Statement	3
1.1	FCC Requirement	3
2	Disposal and Recycling Information	4
3	Precautions	4
4	Package Contents	5
4.1	Projector	6
4.1.1	Touchpad.....	7
4.2	Remote	7
5	Basic Operations	8
5.1	Charging	8
5.2	Power ON	8
5.3	Power OFF	8
5.4	Auto Focus	8
5.5	Keystone Correction	8
5.6	Resizing Projection Screen	9
6	User Interface	10
6.1	Home Screen	11
6.2	Status Icons	12
6.2.1	Status Icon: Battery	12
7	Input Sources	13
7.1	Wireless Display	13
7.1.1	iOS/iPadOS	13
7.1.2	macOS.....	14
7.1.3	Windows.....	14
7.1.4	Android	14
7.2	Wired: HDMI	15
7.3	Wired: USB-C	15
7.4	Memory Device: microSD Card.....	15
7.4.1	Inserting a microSD Card into the projector	15
7.4.2	Ejecting microSD Card	15
7.5	Memory Device: USB storage device	16
8	Product Maintenance	17
8.1	Projector	17
8.2	Remote	17
9	Technical Specifications	18
10	Trademarks	19
11	Regulatory Information	19

1 FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

1.1 FCC Requirement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The end user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body is 1.245 W/kg.

2 Disposal and Recycling Information

Damaged batteries should be treated as hazardous materials. Do not return the device if the battery is swelling, leaking, or if you in any other way suspect that the battery is damaged. In this case, please make sure you dispose of or recycle the item and its accessories according to local laws and regulations. Do not puncture, drop or incinerate the battery.

3 Precautions

- To prevent electric shock, do not open the case. If needed, please ask your local retailer for repair or replacement services.
- When operating the projector: do not look into the lens, as this may cause injury to the eyes.
- To prevent fire or electric shock, do not operate this product in wet or moist environments.
- When using the projector: avoid dropping and impact, as this may damage internal components.
- Always use the included Power Adapter when charging the projector.
- Avoid keeping the Power Adapter plugged in to the projector when it is not in use, unless charging is needed.

4 Package Contents



Projector




Mini Tripod




Power Adapter



Power Plug (EU)



HDMI Cable




USB-C Cable




Remote Control with Gyro

4.1 Projector



4.1.1 Touchpad

The touchpad is located on top of the projector.



How to operate the touchpad:

- Use **one finger** on the center of the touchpad to move the Mouse Pointer.
- Double tap with **one finger** to Confirm (OK).
- Use **two fingers** on the center of the touchpad to scroll up and down.

4.2 Remote



Please note:

- *Hold button to activate the **Mouse Pointer**. The remote control must be paired via **Settings > Remotes & Accessories** before use of this function.
- Handle the remote control carefully. Dropping or jarring the remote can damage internal components.
- Exposure to direct sunlight, smoke or steam can also harm internal components.

5 Basic Operations

5.1 Charging

The projector can be powered by the included Power Adapter or the internal rechargeable battery. To obtain maximum battery life, it is highly suggested that you charge the battery for at least 4 hours the first time.

1. Ensure the projector is turned off and connect it to the Power Adapter.
2. Connect the Power Adapter and the Power Plug (EU).
3. Insert the Power Plug (EU) into a wall outlet to charge the battery.

5.2 Power ON

Press and hold the **ON/OFF** button on the projector for 3 seconds to turn on the projector.

5.3 Power OFF

Press and hold the **ON/OFF** button on the projector for 3 seconds to turn off the projector.

5.4 Auto Focus

Auto Focus is enabled by default. This feature will auto focus the picture on the projected surface. Navigate to **Settings > Projector > Auto focus** to enable/disable Auto Focus.

Please note:

- Ensure that you are projecting on a flat surface. Projecting on uneven surfaces might cause the Auto Focus feature to produce bad results or fail completely.

5.5 Keystone Correction

Keystone Correction enables a skew projection of the output image. Navigate to **Settings > Projector > Four-point keystone** to configure Keystone Correction.

5.6 Resizing Projection Screen


The projection screen size is related to the distance from the projector to the surface on which the display is being projected onto, also known as throw distance. Please refer to the following table for the relationship between throw distance and screen size:

Screen Size	Throw Distance
7"	0.18 m
38"	1 m
56"	1.5 m
100"	2.5 m
200"	4.5 m


Please note:

- The measured values are estimated for reference only.


6 User Interface



Home Screen




Settings Menu



App Shortcuts


6.1 Home Screen

Please refer to the following table for information about the **Home Screen** icons:




Aptoide TV

A free, alternative app store with no restrictions. All apps are free. 2500+ apps available.



Apps

Access all installed apps on the projector.




Files

Access all files available on the projector and browse connected memory devices.




Settings

Access all settings for the projector.




HDMI

Activate HDMI source connected to the projector.



USB-C

Activate USB-C source connected to the projector.



Bluetooth

Quick access to Bluetooth settings.







Wi-Fi

Quick access to Wi-Fi settings.







6.2 Status Icons

Please refer to the following table for information about the **Status Icons** found on the **Home Screen** in the top right corner:

	Auto Focus Indicates Auto Focus on/off.
	Bluetooth Indicates Bluetooth device(s) connected or not.
	Wi-Fi Indicates Wi-Fi connection and signal strength.
	Battery Indicates battery status and battery level.

6.2.1 Status Icon: Battery

Please refer to the following table for information about the battery status and battery level indicator:

	Battery is fully charged.
	The battery level is between 75-99%.
	The battery level is between 50-75%.
	The battery level is between 25-50%.
	The battery level is between 1-25%.
	Battery is charging.






7 Input Sources


There are 3 sources of input: **wireless display**, **wired display** and **memory device**.

7.1 Wireless Display


Wirelessly project the display from any supported device by connecting the device to the same Wi-Fi network as the projector and use the following instructions depending on device and operating system:


7.1.1 iOS/iPadOS

1. Connect your device to the same Wi-Fi network as the projector.
2. Find and play the video that you want to stream.
3. Tap AirPlay . In some apps, you might need to tap a different button first. For example, in the Photos app, tap Share , then tap AirPlay . For the YouTube app, tap Cast , then tap AirPlay and Bluetooth devices .
4. Choose “EShare-XXXX” from the list.




To stop streaming, tap AirPlay  in the app that you're streaming from, then tap your iPhone or iPad from the list.


If you want to use Screen Mirroring instead, follow these steps:

1. Connect your iPhone or iPad to the same Wi-Fi network as the projector.
2. Open Control Center:
 - a. On iPhone X or later or iPad with iPadOS 13 or later: Swipe down from the upper-right corner of the screen.
 - b. On iPhone 8 or earlier or iOS 11 or earlier: Swipe up from the bottom edge of the screen.
3. Tap Screen Mirroring .
4. Choose “EShare-XXXX” from the list.
5. If asked, enter the presented code on your iPhone or iPad.

To stop mirroring your iPhone or iPad, open Control Center, tap Screen Mirroring , then tap Stop Mirroring.

7.1.2 macOS

1. Connect your Mac to the same Wi-Fi network as the projector.
2. Click Control Centre  in the menu bar (top-right), click the Screen Mirroring icon , then choose “EShare-XXXX” from the list.
3. If asked, enter the presented code on your Mac.
4. To set whether your desktop mirrors or extends your Mac screen, click the Screen Mirroring icon , then choose Mirror Built-in Display or Use As Separate Display.


To stop mirroring your Mac, click Control Center , click Screen Mirroring , then click “EShare-XXXX”.

7.1.3 Windows

1. Navigate to **Home Screen > Apps** and open the **EShare** app.
2. Open a web browser on your PC and navigate to the presented URL:
“http://XXX.XXX.X.XX:XXXX”.
3. Choose “Eshare for Windows” from the list.
4. Save the file “Eshare.exe” to desired location on your PC. Refresh the page if the download does not start or if presented with a page error.
5. Locate and open the file “EShare.exe”. If asked, check “Public networks”, then click Allow access.
6. Choose “EShare-XXXX” from the list, then click Share Screen.

To stop mirroring your PC, open the EShare app from the taskbar and click Stop Sharing.

7.1.4 Android

1. Connect your Android device to the same Wi-Fi network as the projector.
2. Open the app drawer or Settings menu:
 - a. On Samsung devices: find and disable Dex.
 - b. On other devices: find and disable any extension functionality.
3. Open the **Wi-Fi Display** app on the projector by navigating to **Home Screen > Apps**.
4. Open the app drawer or Settings menu:
 - a. On Samsung devices: find and tap Smart View , accept any security prompt, choose “NOVA PRO” from the list, then tap Start now.
 - b. On other devices: find and activate Cast/Screen Mirroring/Wireless Display, accept any security prompt, choose “MINI CUBE” from the list, then confirm the action.

To stop casting your device, find and disable Smart View/Cast/Screen Mirroring/Wireless Display.

7.2 Wired: HDMI

Project the display from any device supporting HDMI screen sharing by selecting **HDMI** source from the **Home Screen** and connecting the device via an HDMI cable.

Please note:

- The projector supports 4K HDMI input source at 60 Hz.

7.3 Wired: USB-C

Project the display from any device supporting USB-C screen sharing by selecting **USB-C** source from the **Home Screen** and connecting the device via a USB-C cable.

Please note:

- The projector supports 4K USB-C input source at 60 Hz.

7.4 Memory Device: microSD Card


Make sure to insert the microSD card the correct way to playback and view content. The microSD card should gently be inserted all the way inside the card slot, leaving the microSD card flush with the surface of the projector. Access the memory device content via **Home Screen > Files** or via the device prompt shown at the bottom of the image when inserting the card.

Please note:

- The projector supports microSD cards up to 64 GB for NTFS and up to 32 GB for FAT32.

7.4.1 Inserting a microSD Card into the projector

Use the tip of a fingernail to gently push the microSD card in place with a forwards and down motion.



7.4.2 Ejecting microSD Card

Use the tip of a fingernail to gently push the microSD card inwards to release and eject. Now it is safe to remove the microSD card.

7.5 Memory Device: USB storage device

Connect a USB 2.0 compatible storage device to playback and view content. Access the memory device content via **Home Screen > Files** or via the device prompt shown at the bottom of the image when connecting the storage device.

Please note:

- Some USB storage devices require external power to operate properly.
- The projector supports USB 2.0 storage devices formatted to NTFS and FAT32 with full support for max file size and max hard drive size.

8 Product Maintenance

8.1 Projector

- Charge the battery for at least 4 hours the first time.
- If the projector gets dirty: wipe clean with a dry cloth.
- **Do not** wipe the projector with a damp cloth.

8.2 Remote

The remote control comes with 2 included AAA 1.5 V batteries in the original package. Please use the same type of battery when replacement is needed.

9 Technical Specifications

Native Resolution	960*540 (FWVGA)
Compatible Resolution	Up to 4K
Display Technology	DMD DLP with 3D Support
Light Source	RGB LED OSRAM
Focus	Autofocus, Manual
Brightness (ANSI)	500 Lumens
Contrast	3000:1
Power Supply	DC 12 V, 4 A
Power	36 W
Built-in Speaker	8 Ω , 5 W
Input	USB-C, USB 2.0, HDMI, microSD
Output	3.5 mm Audio Out
Battery	Li-Polymer 10,000 mAh
Dimensions	160 x 90 x 50 mm (W x D x H)
Net Weight	630 g
LED Life Expectancy	>30,000 Hours
Supported Video File Formats	DAT, FLV, MKV, MOV, MP4, MPG, RM, TRP, TS, WMB, RMVB
Supported Audio File Formats	AAC, FLAC, M4A, OGG, MP3, WAV, WMA
Supported Image File Formats	PNG, BMP, JPEG, JPG

Please note:

- The specifications are subject to change without notice.

10 Trademarks

Piczo is a registered trademark of Swede Invent AB, registered in Sweden. Distributed by Swede Invent AB, Säterivägen 16, 65341 Karlstad, Sweden. © 2023 All Rights Reserved. Made in China.

Apple, iPadOS, macOS and AirPlay are trademarks of Apple Inc., registered in the U.S. and other countries. Windows is a registered trademark of Microsoft Corporation in the United States and/or other countries. Samsung, Dex, and Smart View are trademarks or registered trademarks of Samsung Electronics Co., Ltd.. Android is a trademark of Google LLC. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. Wi-Fi and Miracast are registered trademarks of Wi-Fi Alliance. DLP and the DLP logo are registered trademarks of Texas Instruments. DLNA is a registered trademark of Digital Living Network Alliance. SD and related marks and logos are trademarks of SD-3C LLC in the United States, other countries or both. HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing, LLC in the United States and/or other countries. USB Type-C and USB-C are trademarks of USB Implementers Forum. OSRAM is a registered trademark of OSRAM GmbH. Arm and Cortex are registered trademarks of Arm Limited (or its subsidiaries) in the U.S. and/or elsewhere.

11 Regulatory Information

